


Troubleshooting

PROBLEM	CAUSE ANALYSIS	SOLUTION
Headset will not go into pairing mode	Headset must be switched off completely before it will go into pairing mode	Switch off headset and then try to put it in pairing mode again.
Phone cannot find headset	Headset is not in pairing mode or is too far away from phone	Ensure headset is within one or two metres of the phone and that it is in pairing mode.
Pairing fails	PIN error or PIN entry error	1. Make sure you enter the correct PIN code / Passkey. For the headset it is 0000 . 2. Don't take too long to enter the PIN code Try pairing again
Bluetooth link is not established automatically on incoming or outgoing calls	Pairing information in phone or headset has been cleared.	
No voice is heard from the headset when a call is established	Manual switching of voice is needed for some phones.	Use phone menu to transfer voice to the headset.
No voice from phone and headset	Bluetooth function of phone is not working	Use phone menu to transfer voice to the speakerphone
Noise / crackling can be heard during a call	Your phone signal is poor. The headset is too far away from the phone or there is a metal obstruction.	1. Make sure your phone connection is OK 2. Don't take too long to enter the PIN code Make sure the headset and phone are not too far away from each other and that neither is shielded by any metal objects or even your body. 3. A nearby device is interfering with the call. Move away from it.
Headset commands do not work	The display needs to be active before commands will work.	You may need to click any button once to activate the display and hence the command inputs.
Headset commands do not work	Some commands require that the display is blank before they will work.	You may need to wait until the display is blank before you can start the command sequence.
1. Voice dialling does not work 2. You cannot transfer calls from headset to your phone 3. Last number redial does not work 4. Call waiting does not work 5. Call reject does not work	Your mobile phone may not support this feature	1. Make sure your phone supports the feature in general and over Bluetooth 2. If in doubt delete your headset from the list of Bluetooth devices in your phone and try pairing them again.

AURICULAR BLUETOOTH CON IDENTIFICADOR DE LLAMADAS: MANUAL DE FUNCIONAMIENTO



INTRODUCCIÓN

El auricular Bluetooth PMR con pantalla OLED permite identificar las llamadas entrantes, dándole el control de las llamadas sin siquiera sacar su teléfono bluetooth de su bolsillo ó de su maletín.

La combinación de la pantalla iluminada OLED y de las características avanzadas del auricular como : rellamada al último número marcado, números de llamada almacenados, llamada en espera y marcación por voz, permite realizar y recibir llamadas desde el mismo auricular.

El manos libres PMR le ofrece la posibilidad de dejar su teléfono en cualquier lugar y seguir usándolo siempre y cuando dentro de un radio de 10m.


El PMR utiliza la tecnología más reciente bluetooth v1.2 y es compatible con las funciones básicas de los teléfonos móviles con tecnología bluetooth v1.1.

Declaración de Conformidad : Declaramos que el producto PBTOIDX2C2 es conforme con la directiva R&TE de 1999/5/ec y con los certificados CE y FCC. Se puede ver una copia de estos certificados en la web <http://www.pmrtechnology.co.uk/Documents.htm>



PIN PBTOIDX2C2-PMR-RET CE number 0678

DISEÑO DEL AURICULAR



INICIO – Antes de utilizar el manos libres PMR debe:

1. Cargar el auricular durante dos horas como mínimo
2. Ajustar el auricular para que se posicione cómodamente en su oreja
3. Sincronizar el auricular con su teléfono móvil

1. Cargar el auricular: Enchufe el cargador AC a la red y conéctelo en el puerto específico de la orejera del auricular. Se encenderá el LED mientras esté cargando. Cuando esté cargado el LED se apagará, en ese momento puede desconectar el cargador.

Indicador del estado de la batería : Cuando la batería esté completamente cargada el icono de la misma visualizará el nivel de carga en la pantalla. Cuando tenga menos de un 10% de la carga además del icono de batería en la pantalla, el auricular emitirá un sonido de alerta cada 32 segundos.

2. Ajustar el auricular:

El auricular está diseñado para adaptarse cómodamente a su oreja.

El gancho se puede extraer y colocar en el lado opuesto para el uso en cualquiera de las dos orejas. La batería está ubicada en el gancho y por lo tanto el mismo tiene que conectado para poder utilizar el auricular.



Transferring calls (phone dependent)

To transfer calls from your headset (phone dependent)

With the call connected to your headset, press and hold the Talk Button for about 3 seconds until you hear TRANSFER tone. The call will be transferred to the phone handset.

To transfer calls from your mobile phone to your headset

With the call connected to your mobile phone, click the Talk Button on your headset. The call will be switched from the phone to the headset. You may need to activate the display first.

Adjusting the volume

To increase the volume

Whilst in Talk mode, click the Volume UP button to increase volume by 1 step, repeat this procedure until you have reached the desired level.

To decrease the volume

Whilst in talking mode, click the Volume DOWN button to decrease volume by 1 step, repeat this procedure until you have reached the desired level.

Muting the headset microphone

You can mute and un-mute the microphone temporarily so that you cannot be heard by the connected party.

To mute the headset

Whilst in Talk mode, press and hold the Volume UP button for 3 seconds. The headset microphone will be switched off and the headset will beep every four seconds to indicate that it is still muted.

To un-mute the headset

When microphone is muted, press and hold Volume UP button for 3 seconds. The headset microphone will become active again and you should be able to speak to your caller.

Customer Support

In addition to the troubleshooting table on the next page you can get support on the PMR support forum at this web address <http://www.esktech.com/forums/>

For other PMR Bluetooth products or support, please contact PMR Technology Ltd

Email: support@pmrtechnology.co.uk

Web: www.pmrtechnology.co.uk

DISCLAIMER

Whilst every effort has been made to ensure that the information in this manual is accurate and complete, no liability will be accepted for any errors and/or omissions made. The manufacturer reserves the right to make changes and improvements to the specifications and features of the hardware and firmware of the products described in this document without prior notice. Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form is prohibited without prior permission of the manufacturer. All trademarks acknowledged.

Version: QSGPMR CIDVer13

Ending a call

When you have finished your call, simply click the Talk Button on your headset. The call will be disconnected.

Incoming calls

Notes:

1. For some mobile phones you must configure your phone to answer calls directly on your Bluetooth headset. Refer to the mobile phone user guide for instructions on activating this feature.
2. You can use the Caller ID features (see the next section) to decide whether or not to accept the call.
3. When a call comes in you may hear the mobile phone ring before the headset rings. This small delay is normal. It is usually best to wait for the headset to ring before accepting or rejecting a call.
4. The display will show "Ring" when there is an incoming call.

Accept a call

When your mobile phone and headset rings, simply click the Talk Button. The call will be connected automatically to your headset and "Answered" will be displayed.

Reject a call

When your mobile phone and headset rings, press and hold the Talk Button for approx 3 seconds until you hear the Call Reject tone. The call will be rejected and "Reject" displayed on the headset.

To Accept a Call Waiting Call (if supported by your phone)

If your mobile phone supports Call Waiting you can answer a second call even though you are already on a call. The first call is put on hold while the second one is answered. You can switch back and forth between both calls.

1. If you are on a call and you hear the Call Waiting tone ..
2. Press and hold the Volume DOWN button for 3 seconds
(The first call will be placed on hold and the second call connected to the headset)
3. To switch between calls press and hold the Volume DOWN button again.
(The second call will be placed on hold and the first call reconnected)

Showing Caller ID and Caller Name (phone dependent)

Caller ID display (CID) shows the name and number on the headset display whenever there is an incoming call. *Note: Currently, Caller ID headset just supports English caller names.* You can disable and enable the Caller ID/Name display function so that others cannot see the number or name of your caller.

To enable the caller ID display (if supported by your mobile phone)

When the caller ID display function is disabled, press & hold both the Volume UP and Volume DOWN buttons at the same time; "CID enabled" will be shown on the headset display.

To disable the caller ID display

Press and hold both the Volume UP and Volume DOWN buttons at the same time; "CID blocked" will be shown on the headset display.
"CID blocked" will also be displayed when there is an incoming call.

Colocar el gancho en la oreja

Posicione el gancho sobre la parte superior de la oreja y colóquelo en su oreja. El micrófono en la parte delantera del auricular debe de estar orientado hacia la boca.

Cambiar la dirección del gancho (no doble el gancho para moverlo).

Sosteniendo la parte estrecha del gancho cuidadosamente retirelo del cuerpo del auricular, inserte el conector del gancho en el lado opuesto del mismo auricular.

3. Sincronizar el auricular con su Teléfono móvil:

Antes de poder utilizar el auricular con su teléfono deberá sincronizar (proceso de unión) los dos dispositivos

Después de la sincronización Vd. Podrá únicamente utilizar el auricular con el teléfono con el teléfono que ha sido sincronizado. Si desea utilizarlo con otro teléfono móvil deberá repetir el proceso de sincronización con el nuevo teléfono. En este caso el auricular dejará de funcionar con el teléfono anterior.

Antes de iniciar el sincronizado asegúrese de que la batería esta cargada.

1. Revise la guía de uso de su teléfono para saber como activar la conexión bluetooth y como sincronizarlo con un auricular bluetooth.
2. Encienda el teléfono y colóquelo a una distancia de uno o dos metros del auricular. Active la opción bluetooth en su teléfono.
3. Con el auricular apagado presione y sostenga aproximadamente durante 5 segundos el botón TALK. Aparecerá en la pantalla "PAIRING" y podrá escuchar el tono de encendido seguido por un tono de sincronización.
4. Libere el botón de TALK. El auricular ya está en modo sincronización
5. Ponga su teléfono en la modalidad de búsqueda de dispositivos bluetooth.
6. El teléfono identificará el auricular y aparecerá en la pantalla del mismo como "desconocido" o como "BTHS".
7. El teléfono le pedirá que introduzca el código pin, entonces debe marcar 0000.
8. Cuando se haya realizado la sincronización el auricular se pondrá en espera y la palabra "READY" aparecerá en la pantalla. El LED azul parpadeará cada 2 segundos.

Para cancelar la sincronización:

Cuando el auricular indique "PAIRING" podrá detener el proceso de sincronización y apagar el auricular. Presione y sostenga la tecla "TALK" durante 3 segundos. "OFF" aparecerá en la pantalla del auricular, que emitirá el tono de "apagado".

UTILIZAR EL AURICULAR PMR

El auricular PMR y su teléfono móvil seguirán sincronizados aunque se apaguen. No necesita sincronizarlos cada vez que enciende su teléfono o auricular.

Encender el Auricular

Presione el botón "TALK" durante aproximadamente 4 segundos, hasta que la pantalla se encienda y se pueda ver la palabra "STAND BY". También se oirá el tono de "Encendido". El auricular ahora está listo para realizar y recibir llamadas. Si el auricular no se utiliza durante 18 segundos, la pantalla pasará al modo "ahorro de batería". La pantalla se vuelve a activar presionando una vez cualquier tecla. Ciertas teclas solo funcionan cuando la pantalla está activa.
El LED azul parpadeará indicando que el auricular está en funcionamiento.

Apagar el Auricular

Presione y sostenga el botón "TALK" durante aproximadamente 4 segundos hasta que la palabra "OFF" se muestre en pantalla y la misma quede en blanco. También oírás el tono de "Apagado" y el LED dejará de parpadear.

INDICADORES DE FUNCIONAMIENTO VISIBLES O ACUSTICOS

El auricular PMR utiliza 3 modos para indicarle que está en funcionamiento, el LED azul, los tonos acústicos y los indicadores de pantalla.

1. LED AZUL


Cuando el auricular está encendido parpadeará aproximadamente cada 3 segundos

2. INDICADORES ACUSTICOS

NOMBRE DEL TONO	SONIDO	QUE INDICA
ON	3 NOTAS ASCENDENTES	ENCENDIDO
OFF	3 NOTAS DESCENDENTES	APAGADO
SINCRONIZAR	2 NOTAS ALTO/BAJO	SINCRONIZACIÓN
LLAMADA	4 NOTAS ASCENDENTES	LLAMADA ENTRANTE
RECHAZAR LLAMADA	2 NOTAS REPETIDAS ALTO/BAJO	LLAMADA RECHAZ.
LLAMADA EN ESPERA	BEEP – NOTA REPETIDA	2ª LLAMADA
SIN BATERIA	1 NOTA REPETIDA CADA 32 s	NECESITA CARGAR
SILENCIADO	1 NOTA REPETIDA CADA 4 s	MICRO APAGADO
TRANSFERIR	5 NOTAS ALTO/BAJO	TRANSFERIR

3. PANTALLA (Algunas características dependen del teléfono móvil)

La pantalla dispone de hasta 4 secciones que incluyen iconos, identificador de llamadas, nombre y estado de la llamada



Los Iconos:

El 1er icono indica el estado del auricular

— Indica que no hay conexión de audio en el auricular.

— Indica que el auricular está conectado y en espera para hablar

El 2º icono indica el estado de conexión del auricular.

— Indica que el auricular está esperando para ser conectado al móvil

— Indica que el auricular está conectado al móvil

El 3er icono es el icono de volumen

— Indica el actual nivel de volumen.

El 4º icono es el icono de la batería.

— Indica el nivel de carga de la batería

To make calls from your mobile phone

Dial the number on your mobile phone. Depending on your phone's Bluetooth settings you will hear the call ringing in the headset and the call will be connected automatically to the headset when it is answered.

To make calls using voice dialling (if supported by your mobile phone)

1. Click any button on your headset to activate the display.
2. Click the Talk Button to connect to the phone. You will hear a short beep, "Voice Dial" will appear on the headset display and your phone should activate.
3. After a second beep, speak the name of the person you wish to call. Your mobile phone will acknowledge your voice command and dial the appropriate number (depends on phone).
4. The call will be connected automatically to the headset when it is answered.

To make calls using last number redial (if supported by your mobile phone)

1. Click any button on your headset to activate the display.
2. Press and hold either the Volume UP or the Volume DOWN on your headset for 3 seconds.
3. "Redial" will appear on the display and the last number dialled from your mobile phone will be dialled automatically and the headset connected when the call is answered.

To make calls using headset Stored Numbers

This list of numbers represents incoming calls to the phone and headset.

1. With the headset display blank (blue LED is flashing but display is blank)
2. Click the Volume UP button. The display will turn on and the headset will enter stored number browsing mode.
3. Click the Volume UP or DOWN buttons to scroll through the stored numbers.
4. When your desired number is displayed click the Talk Button. The call will be dialled automatically and the headset connected when the call is answered.

To make calls using your mobile's phone book (if supported by your mobile phone)

1. With the headset display blank (blue LED is flashing but display is blank)
2. Click the Volume DOWN button. The display will turn on and the headset will enter phone book browsing mode.
3. Click the Volume UP or DOWN buttons to scroll through the numbers stored in your mobile phone's main memory
4. When your desired number is displayed click the Talk Button. The call will be dialled automatically and the headset connected when the call is answered.

View your mobile's phone book (if supported by your mobile phone)

You can view and browse the phone book in your mobile phone using only the headset controls and display. The controls are described in the section above 'To make calls using your phone book'.
Notes:

1. The headset only accesses the phone memory – not the SIM card.
2. The headset accesses the phone memory using the order in which the numbers were stored – not in alphabetical order
3. Viewing your mobile's phone book automatically enables the Caller ID feature.